





DATA SHEET



Hygrostat





Measuring range from 5 to 95% HR



Measuring range from 0 to $50^{\circ}C^{(1)}$ or from -20 to +80°C⁽²⁾

Features

- RCR relay output 3A/240 Vac (NC), power supply 24 Vac/Vdc
- Visual and audible alarm configurable on one or two parameters, red led in front
- ABS V0 IP65 housing⁽²⁾ or IP20⁽¹⁾
- · Alternating display of humidity and temperature
- "1/4 turn" system mounting with wall-mount plate
- Housing with simplified mounting system

Part number

Measured parameters

Parameters	Accuracies ⁽³⁾	Measuring ranges	Resolution	HST -
Temperature	Ambient model: $\pm 0.4\%$ of reading $\pm 0.3^{\circ}$ C Duct and remote models: $\pm 0.3^{\circ}$ C (from -40°C to 70°C); $\pm 0.5^{\circ}$ C beyond	Ambient model: From 0 to 50°C Duct and remote models: From -20 to +80°C	0.1°C	Probe S: Ambient A: Duct D: Remote
Hygrometry ⁽⁴⁾	Duct and remote models: $\pm 1.5\%$ RH (if $15^{\circ}C \le T \le 25^{\circ}C$) Ambient model: $\pm 2\%$ RH (if $15^{\circ}C \le T \le 25^{\circ}C$)	From 5 to 95% RH	0.1% RH	Example: HST – A Hygrostat HST with duct probe

Technical specifications

Output	1 RCR relay. NO (normally opened): 5A / NC (normally closed): 3A / 240 Vac. Common mode voltage <30 Vac		
Power supply	24 Vac/Vdc ±10%		
Consumption	3 VA		
Relay and alarm status	Red led in front and internal buzzer (70 dB at 10 cm)		
European directives	2014/30/EU EMC; 2014/35/EU Low Voltage; 2011/65/EU RoHS II; 2012/19/EU WEEE		
Electrical connection	Terminal block for cables Ø0.05 to 2.5 mm ² . Carried out according to the code of good practice.		
PC Communication	USB-mini Din cable		
Environment	Air and neutral gases		

 $^{^{\}mbox{\scriptsize (1)}}$ Ambient model / $^{\mbox{\tiny (2)}}$ Duct or remote model

⁽³⁾ All the accuracies indicated in this technical datasheet were stated in laboratory conditions, and can be guaranteed for measurements carried out in the same conditions, or carried out with calibration compensation.

 $^{^{(4)}}$ Drift linked to temperature: ± 0.04 x (T-20) %RH (if T $< 15^{\circ}C$ or T $> 25^{\circ}C)$

General features


Unit of measurement °C, °F, % HR Temperature: NTC Type of sensor Hygrometry: capacitive Temperature: 1/e (63%) 15 s Response time Hygrometry: 1/e (63%) 4 s Type of fluid Air and neutral gases Conditions for use From 0 to +50°C. In non-condensing condition. (°C/%HR/m) From 0 to 2000 m. Operating temperature of From -20 to +80°C the probe


Features of the housing

Material	ABS V0 as per UL94		
Protection	IP20		
Display	LCD 10 digits. Size: 50 x 17 mm Alternating display of humidity and temperature Height of digits: Values: 10 mm. Units: 5 mm		
Weight	138 g		


Dimensions

Storage temperature






From -10 to +70°C



Ambient model



Duct model

Connections

Inside the front housing



- Inactive switch
- Active switch (S1)
- 3. LCC-S software connection
- Alarm Led

Removable front face





- 5. **Button for settings**
- Relay terminal block
- 7. Power supply terminal block
- Cable gland

Electrical connectios as per NFC15-100 standard




This connection must be made by a qualified technician. To make the connection, the transmitter must not be energized.

NO: normally opened COM: common NC: normally closed

NO COM NC 3 Power supply

Fixed back housing



or

Settings and use of the transmitter


Configuration

It is possible to set the unit of the transmitter either by switch and/or via software.



To configure the transmitter, it must not be energized. Then, you can make the settings required, with the DIP switches (as shown on the drawing below). When the transmitter is configured, you can power it up.

Configuration by switch: to configure the transmitter, unscrew the 4 screws from the housing then open it.





Please follow carefully the combinations beside with the DIP switch. If the combination is wrongly done, the following message will appear on the display of the transmitter "CONF ERROR". In that case, you will have to unplug the transmitter, place the DIP switches correctly, and then power the transmitter up.

Units setting – active switch

To set a unit of measurement, put the on-off switch 4 of the units as shown beside.

• Threshold configuration

The button allows to activate or not an alarm (threshold), to set the action of the alarm (edge), to set the threshold(s) value, to set the time-delay and to acknowledge the alarm.



Working principle:

- By pressing the button more than 3 seconds, you can validate the setting and go to the next setting.
- By pressing quickly the button, you can increment a value and scroll down the different option or values.

Activate or deactivate an alarm

- Press the button for 3 seconds, "CONF" is displayed then "NEG", meaning that the relay is in negative security, it is excited during an alarm condition.
- If needed, press quickly the button to switch the relay in positive security, the relay is de-energized during an alarm condition or a current breaking, "POS" is displayed.
- Press 3 s the button, "Buzz" screen is displayed with "ON" or "OFF" blinking. Briefly press on the button to activate ("ON") or deactivate ("OFF") (according to the last saved configuration) the buzzer during an alarm condition.
- Press 3 s the button, "Alarm" screen is displayed with "On" or "Off" blinking (according to the last saved configuration).
- Press quickly the button, the display changes from "On" (activated alarm) to "Off" (deactivated alarm).
- Press 3 seconds the button to confirm the setting. If the alarm is deactivated, the instrument displays the measurement; if the alarm is activated, the instrument displays the following setting.

• Set the action of the alarm (rising edge or falling edge)


The edge determines the action of the alarm according to the trespassing direction of the threshold(s).


Mode Mode Mode

Rising edge (1 threshold): the alarm goes off when the measurement exceeds the threshold and stops when it is below the threshold.


Falling edge (1 threshold): the alarm goes off when the measurement is below the threshold and stops when it exceeds the threshold.

Monitoring (2 thresholds): the alarm goes off when the measurement is outside the defined low and high thresholds.






Measurement (m) < Threshold (S) - Hysteresis (H) during the time-delay T2: Alarm deactivation.



Measurement (m) < Threshold (S) during the time-delayT1: Alarm activation.

Measurement (m) > Threshold (S) + Hysteresis (H) during time-delay T2: Alarm deactivation.



The alarm goes off when the measurement is outside the low and high thresholds.

- Press briefly the button to select the trespassing direction then press the button more than 3 seconds to validate this direction and set the thresholds.

• Set the threshold(s) value

The first digit blinks, it corresponds to the positive (0) or negative (-) setting of the threshold value. Press briefly on the button to select the sign for the threshold value. Press on the button more than 3 seconds to validate.

The second digit blinks, press briefly on the button to scroll the numbers. Press the button more than 3 seconds to validate. Repeat the process until the last digit to configure the threshold value, validate the threshold and go to the following setting. If the monitoring edge has been selected, the transmitter displays the setting of the second threshold.

• Set the hysteresis

The hysteresis is only for the rising edge and the falling edge modes.

In rising edge mode, the hysteresis allows to the transmitter to stay in alarm when the measurement is between the threshold and the threshold minus the hysteresis.

Ex: for a 50% RH threshold and a 10% RH hysteresis, the instrument will stay in alarm when the measurement will be between 50 and 40% RH. In falling edge mode, the hysteresis allows to the transmitter to stay in alarm when the measurement is between the threshold and the threshold plus the hysteresis.

Ex: for a 100% RH threshold and a 10% RH hysteresis, the instrument will stay in alarm when the measurement will be between 100 and 110% RH. The first digit blinks, set it pressing the button briefly several times then press on the button more than 3 seconds to set the following digit..

Once the hysteresis is set, press the button more than 3 seconds to validate and set the time-delays.

- Set the time-delay 1 and the time-delay 2 (600 seconds maximum)
- In rising edge mode, the time-delay 1 corresponds to the time lag before the alarm goes off when the threshold has been reached. The time-delay 2, corresponds to the time lag before the alarm stops when the measurement is lower than the threshold minus the hysteresis.

Setting procedure: "Time 1" for the time-delay 1 is displayed then the time in second. The first digit blinks, press briefly on the button and scroll the figures. Press on the button more than 3 seconds to validate. Repeat the process until the last digit to set the time-delay 1 value (from 0 to 600 s) and validate. "**Time 2"** is displayed the time in second. Repeat the process to set the time-delay 2.

- In falling edge mode, the time-delay 1 corresponds to the time lag before the alarm goes off when the threshold has been reached. The time-delay 2, corresponds to the time lag before the alarm stops when the measurement is lower than the threshold plus the hysteresis. The setting procedure is the same as the rising edge procedure.
- In monitoring mode, the alarm of the transmitter goes off when the measurement is below the lower threshold and higher the high threshold. The time-delay 1 corresponds to the time lag before the alarm goes off when the measurement is below the lower threshold and higher the high threshold. The time-delay 2 corresponds to the time lag before the alarm stops when the measurement is between the lower and higher thresholds.

The setting procedure is the same as the rising edge procedure.

Configuration via LCC-S software (optional)

The software allows to set the alarms, the thresholds, and the time-delay of the transmitter

- To access the configuration via software:
 - Set the DIP switches as shown beside.
 - Connect the cable of the LCC-S to the connection of the transmitter.
- Please refer to the user manual of the LCC-S to make the configuration.





The configuration of the parameters can be done either with the DIP switch or via software (you can not combine both solutions). Switch off the sensor before settings process.


Mounting

To mount the transmitter, mount the ABS plate on the wall (drilling: Ø6 mm, screws and pins are supplied).

Insert the transmitter on the fixing plate (see A on the drawing beside). Rotate the housing in clockwise direction until you hear a "click" which confirms that the transmitter is correctly installed.



Ambient model does not have any mounting plate.
4 fixing holes are present inside the back housing.
Use them to install the transmitter on the required location.



Maintenance

Please avoid any aggressive solvent. Please protect the transmitter and its probes from any cleaning product containing formalin, that may be used for cleaning rooms or ducts.

Precautions for use

Please always use the device in accordance with its intended use and within parameters described in the technical features in order not to compromise the protection ensured by the device.

Options and accessories

Name	Reference
Power supply class 2, 230 Vac input, 24 Vac output	KIAL-100A
Configuration software with USB cable	LCC-S
Stainless steel sliding fittings	-
PC cable gland	-
ABS connection with connection gland	-
Stainless steel connections	-
Wall-mount plate for humidity remote probe	-



Only the accessories supplied with the device must be used.



